



**ROOF EDGE DETAIL WITH PRESSURE SEAL**  
**FULLY BONDED SYSTEM**

DRAWING: SOP-008

SCALE: Not to scale

EFFECTIVE DATE: 15-03-2019



# Roof Edge Detail With Pressure Seal Fully Bonded System

Prior to Membrane Installation, Review the Data Sheet

## **Surface Prep**

It is the contractor's responsibility to inspect all areas which are to receive the waterproofing membrane and report any unsatisfactory conditions to the main contractor. Refer to the technical data sheet for detailed specifications for preparing various substrates.

The surface to be waterproofed must be clean and sound. Remove all dust, dirt, laitance or any other contaminants which may hinder adhesion of the membrane.

## **Special Notes**

Downturn to extend a minimum of 100mm from the junction.

Seal top edge of metal flashing with Sopramastic Alu or compatible sealant approved by Allnex.