



BITUTHENE 3000 LAP ONTO DPC (POLYTHENE)

BITUTHENE WATERPROOFING SYSTEM

DRAWING: BIT-030

SCALE: Not to scale

EFFECTIVE DATE: 01-03-2019

Bituthene 3000 Lap Onto DPC (Polythene)



Prior to Membrane Installation, Review the Bituthene[®] Data Sheet

Surface Prep

All surfaces must be structurally sound and free from spalled areas, loose aggregate, sharp protrusions or other matter that may hinder the adhesion or regularity of the membrane installation. The surface should also be free from frost, dirt, grease, oil or other contaminants as outlined in the Bituthene[®] Data Sheet section on Surface Preparation. Clean loose dust and dirt from the surface and prime with appropriate primer.

Detailing

1. Tape the loose DPC onto the face of the footing using strips of Preprufe Detail Tape. .
2. Lap Bituthene 3000 onto the face of the footing by a minimum of 150mm.
3. Seal bottom edge of Bituthene 3000 onto DPV using Bituthene LM3000.

Special Notes

Bituthene membranes should not be used in areas where they will be permanently exposed to sunlight, weather or traffic. Protect membrane from sunlight as quickly as possible after installation.