



**INSIDE CORNER 2 PLY
MOD-BIT WITH A FILLET**

DRAWING: SOP-015

SCALE: Not to scale

EFFECTIVE DATE: 15-03-2019



Inside Corner 2 Ply Mod-Bit With A Fillet

Prior to Membrane Installation, Review the Data Sheet

Surface Prep

It is the contractor's responsibility to inspect all areas which are to receive the waterproofing membrane and report any unsatisfactory conditions to the main contractor. Refer to the technical data sheet for detailed specifications for preparing various substrates.

The surface to be waterproofed must be clean and sound. Remove all dust, dirt, laitance or any other contaminants which may hinder adhesion of the membrane.

Special Notes

1. Allnex/Soprema detail drawings refer to Allnex/Soprema and other related published documentation, product data sheets (PDS) and safety data sheets (SDS) for additional information. All detail drawings and related installation guidelines are provided by Allnex/Soprema for the sole purpose of issuing a product warranty. Accordingly the detail drawings are not offered and should not be considered as a substitute for professional design services.
2. Hot Work: the contractor is responsible for determining appropriate conditions to utilize heat welding equipment. Refer top local codes and building owner's requirements for hot work operations.
3. Primer: where not shown or indicated on detail drawings, refer to material product data sheets for primer application requirements.