



**EDGE PROTECTION OVER A PARAPET
WITH A FILLET**

DRAWING: SOP-010

SCALE: Not to scale

EFFECTIVE DATE: 15-03-2019



Edge Protection Over A Parapet With A Fillet

Prior to Membrane Installation, Review the Data Sheet

Surface Prep

It is the contractor's responsibility to inspect all areas which are to receive the waterproofing membrane and report any unsatisfactory conditions to the main contractor. Refer to the technical data sheet for detailed specifications for preparing various substrates.

The surface to be waterproofed must be clean and sound. Remove all dust, dirt, laitance or any other contaminants which may hinder adhesion of the membrane.

Special Notes

- (i) There must be a water seal under heads of fixings, top fixing not allowed.