

MANUAL SECTION	ISSUE DATE	AUTHORISED	REPLACES	PAGE
Waterproofing	September 2016		Jan 2012	1 of 4

TERRAFLEX
REINFORCED ACRYLIC DECKING MEMBRANE

DESCRIPTION: Terraflex is a fibreglass reinforced waterproofing deck membrane. It is liquid applied in-situ to adapt to the design and shape of the area being waterproofed. It is based on a high quality, durable acrylic resin.

FEATURES:

- Aquaguard 101 Basecoat Full bonding
- Laminated Will conform to complex shapes and upturns, down turns.
- Single component body coat
- Durable acrylic system
- Colour choice
- Water resistant

Technical

Compliant with NZBC within B2 Durability and E2 water ingress. Terraflex 15 year durable as Terraflex is an exposed membrane.

- Proven adhesion to a variety of substrates in difficult environments
- Easy to use and apply
- Long life, UV stable, Light Foot traffic suitable.
- Light colours only recommended
- Long life

RECOMMENDED USES:

- Decks, patio’s, suspended decks, roofs
- For use over concrete and well fixed plywood
- For waterproofing complex shapes
eg balustrades; curved surfaces, curved balustrades. Multidirectional shapes

LIMITATIONS:

- For use for exposed deck surfaces only (ie uncovered).
- It is dependent on a stable, non-moving substrate. This is particularly true for plywood which must be well fixed. Terraflex does not hold a weakly installed deck together.
Terraflex is a membrane; some blistering and peaking on joints often occurs due to the plywood/slab expansion and contraction. Structural movement will lead to the sheet substrate moving and this is often expressed at sheets joints in peaking of the membrane at that point.
- Do not apply in multiple wet layers or apply so thickly so that it does not through dry. Ensure each layer is fully through dry before proceeding. Otherwise blisters may occur.

SURFACE PREPARATION:

Concrete

Allow full 28 days cure time after the concrete pour. Diamond grind the concrete to prepare the concrete prior to priming. Ensure surfaces are clean/dry and free from surface contaminants. Check falls and reset falls if necessary using Lockfast Floor Levelling Compound (FLC).

No warranty either expressed or implied or statutory is made by NUPLEX in this document except as expressly stated in any sale and purchase agreement entered into between NUPLEX and the buyer. CERTIFIED ISO 9001 REG. NO. 158
This document is a technical data information sheet The description of the product or products and the properties of the product or products contained in this document is for the sole purpose of identifying the product or products and describing their property or properties and does not constitute a warranty that the product or its properties shall conform to that description; nor is the description of the product and/or its properties a warranty by NUPLEX that the goods are suitable for a particular purpose.

NUPLEX CONSTRUCTION PRODUCTS WWW.NUPLEXCONSTRUCTION.CO.NZ
 PO Box 1 2841, Penrose, Auckland Telephone: 0-9-579 2029, Fax: 0-9-525 3709, Email: bpdsales@nuplex.co.nz

H A M I L T O N	P A L M E R S T O N	N O R T H	W E L L I N G T O N	C H R I S T C H U R C H
Telephone: 0-7-847 8658	Telephone: 0-6-353 3685	Telephone: 0-4-477 7040	Telephone: 0-3-366 6802	
Fax: 0-7-847 3766	Fax: 0-6-353 3632	Fax: 0-4-477 7039	Fax: 0-3-379 0279	

Plywood / Compressed sheet Decks/Roof

Traffic deck substrates must be strong. Fixing of the sheets is critical. See limitations above. The plywood should be CCA treated, minimum 20mm thickness. Allow 1-2mm between sheets when laid. The plywood should be mastic bonded to the framing timber and stainless steel screw fixed. Most failures of these systems are due to excess movement due to inadequate fixing of the plywood or inadequate structural framing. Stainless steel screw fix. Fixing should be at 150mm perimeter centres and 200 internal centres. Fixing heads must be sub-surface. Flush fill all screw heads and sheet joints using Nuplex Fairing Cream. Allow good falls to allow water run-off. Sand all joints flush. Sand total surface. **Note:** The coating contractor should carefully inspect the substrate work prior to commencement. Any unsatisfactory areas to be corrected.

For Both Concrete and plywood.

Plan all upstands carefully and ensure that any cladding has good cover over the upstands. 150mm overcover would be a minimum. A kickout at the top of any upstands to prevent water blowing up is recommended. Also any doorways should have waterstops to prevent driven water.

Priming

Prime all substrates as prepared with Aquaguard 101. This should be applied as one coat at approximately 5m²/mixed litre. Mix and apply Aquaguard 101 as per data sheets and specification. Allow the Aquaguard 101 to cure 24 hours prior to proceeding. Take care to apply Aquaguard 101 into joint areas with a brush. Take care to treat surface and prime all vertical wall areas i.e. coves.

Application Conditions

Products such as Terraflex require **good drying conditions** to allow water to evaporate from the coating. Do not apply in temperatures less than 10°C or when wet weather is likely. Good **air movement** is the best method of drying waterbased products.

Working in hot, dry windy conditions will be difficult as the material will setup too rapidly. Study weather forecasts to ensure that the material will be fully and through dry prior to any rain.

Joints

All joints should be taped prior to the full membrane application. Joints will require Nuplex 100mm reinforcing tape. Use slip joint lap (Joint safe tape) prior in any high movement areas. Wider strips will be needed to form coves. In all cases, apply a heavy coat of Terraflex body coat and lay in the CSM strip and apply a further body coat. Immediately use a metal laminating-roller (refer to Nuplex range) to bring the body coat up through the CSM. Use a garden sprayer to apply a **fine water mist**. This ensures that the Terraflex is fluid and wets the glass readily.

Allow to fully dry (test), prior to the full membrane installation.

MEMBRANE:

Following priming and joint preparation, roll a full coat of Terraflex body coat over the whole surface. Include roll-downs into drains and cove ups behind flashings. Lay the 300gsm mesh into the body coat. Allow minimum 75mm overlaps. This is a critical step and take care this minimum 75mm overlap is achieved. Roll the entire surface with a laminating roller. This will bring up the body coat through the mesh. It is **important** that the pressure of the roller brings material up, rather than trying to force it down. This process ensures the **inside of the CSM** is "wetted" by the Terraflex. The sufficient quantity is indicated by surplus spots being forced up by the action of the roller. Apply a second coat of Terraflex wet on wet and roll evenly.

Allow these coats to dry (test thoroughly dry) and follow with a third coat of Terraflex. Allow to dry and glaze surface with one thin coat of Terraflex tinted appropriately. Allow to dry.

Optional: Use Aquaglaze UV to add gloss and to help reduce scuffing.

Apply one thin coat at 10m²/lt.
Apply sealant to all areas as appropriate.

Note

Terraflex is a membrane; some blistering and peaking on joints often occurs due to the plywood/slab expansion and contraction. This is not a factor of the membrane, rather it is the substrate and/or the structure moving.

COVERAGE:

Aquaguard 101 Primer	5-8m ² /Lt
1 st body coat Terraflex	1m ² /Lt
Chopped strand mat	1m ²
2 nd body coat Terraflex	3m ² /Lt
3 rd coat Terraflex	6-8m ² /Lt
Colour Glaze coat Terraflex	8m ² /Lt
Gloss coat: Aquaglaze UV	10m/ Lt - optional

It is important that more **thinner** coats are applied, rather than fewer thicker coats. Excessively thick coats retard drying and may lead to blisters.

Requirements for 100m²

- 20 lt kit of Aquaguard 101 (10 lt A + 10lt B)
- 100m² roll Chopped fiberglass matt
- 10 x 15lt Terraflex.
- 1 – 2 x 10lt pails Tinted Terraflex
- 2-3 x 4lt Aquaglaze UV - optional

CLEAN UP:

All components clean up in water.

MAINTENANCE:

Inspect yearly.
Membrane peaking is indicating deck movement. Inspect.
Re-apply Terraflex as appropriate.
Low wear decks should be recoated every 5 years with Terraflex.
Do not allow wear to damage fibres of the CSM material.

HEAVY DUTY AREAS:

Include a second layer of mesh in the 3rd body coat of Terraflex and add a 4th coat to the system. This markedly improves wear and impact resistance. Edge and step details may be further reinforced in this way.

PRODUCER STATEMENT

Compliant with NZBC B2 Durability and E2 water ingress: 15 year durable as Terraflex is an exposed membrane.
Undertake regular inspections. Terraflex should be reglazed as appropriate (every 5 years or more often depending on wear). Apply new fiberglass and Terraflex on any weak areas. Specifically excluded is cracking in substrates, which exceeds the movement capability of the Terraflex system. The user should note that wrinkling or seaming is due to substrate movement.

Nuplex Industries Ltd state that the Terraflex system is compliant with the Building Act. This technical data sheet is to be read in conjunction with other relevant technical data sheets. If any doubt or confusion exists please contact Nuplex.

