



NOTES: -THE FOOTING KEYWAY SHOULD BE FORMED TO CREATE A REGULAR AND UNIFORM SHAPE ALLOWING PROPER DETAILING OF THE BITUTHENE LIQUID MEMBRANE.



**FOUNDATION WALL
FLOOR SLAB AT FOOTING LEVEL (OPTION 4)
BITUTHENE WATERPROOFING SYSTEM**

DRAWING: BIT-004

SCALE: Not to scale

EFFECTIVE DATE: 01-03-2019



Foundation Wall

Floor Slab At Footing Level (Option 4)

Prior to Membrane Installation, Review the Bituthene® Data Sheet

Surface Prep

All surfaces must be structurally sound and free from spalled areas, loose aggregate, sharp protrusions or other matter that may hinder the adhesion or regularity of the membrane installation. The surface should also be free from frost, dirt, grease, oil or other contaminants as outlined in the Bituthene® Data Sheet section on Surface Preparation. Clean loose dust and dirt from the surface and prime with appropriate primer.

Detailing

1. Apply Bituthene Liquid Membrane to a thickness of 90-mil (2.3 mm) on the horizontal surface of the footing in the keyway. Extend the Liquid Membrane a minimum of 65 mm onto the horizontal surface of the footing on each side of the foundation wall, and extend up the external foundation wall surface a minimum of 65 mm.
2. Apply a strip of Bituthene membrane onto the Liquid Membrane that extends beyond the internal foundation wall surface.
3. Apply Preprufe® membrane in accordance with the Preprufe data sheet and overlap the Preprufe membrane onto the Bituthene Strip a minimum of 75 mm.
4. Install Preprufe CJ Tape centred over the edge of the Preprufe membrane and adhere it to the Bituthene strip and Preprufe membrane.
5. Apply a termination seal of Bituthene Liquid Membrane along the Preprufe Tape and Bituthene Strip termination.
6. Install the Bituthene on the wall in accordance with the Bituthene Data Sheet section on installation.
7. Apply bead of Liquid Membrane on all terminations.
8. Apply Preprufe and NPX according to the installation instructions found on the data sheet.

Special Notes

Bituthene membranes should not be used in areas where they will be permanently exposed to sunlight, weather or traffic. Protect membrane from sunlight as quickly as possible after installation.

Ensure Adcor® waterstop is encapsulated with 75 mm of concrete cover minimum.

Apply Adcor® waterstop according to the installation instructions found on the data sheet.

Allnex may require an alternative GCP waterstop based on design conditions, at Allnex's discretion.